



HURACAN-LT V210

DMX channel's functions and their values (70DMX channels):

Mode/Channel	Value	Function
1	1	1
	0-255	PAN Movement 8bit : Pan Movement
2	2	
	0-255	Pan Fine 16bit Fine control of Pan movement
3	2	3
	0-255	TILT Movement 8bit : Tilt Movement
4	4	
	0-255	Tilt Fine 16bit Fine control of Tilt movement
5	3	5
	0-225	Speed Pan/Tilt movement: max to min speed
	226-235	blackout by movement
	236-245	blackout by all wheel changing
	246-255	no function
6	4	6
	0-10	Shutter, strobe: Shutter closed
	11-20	No function (shutter open)
	21-117	Strobe effect slow to fast
	118-126	No function (shutter open)
	127-180	Pulse-effect in sequences
	181-191	No function (shutter open)
	192-245	Random strobe effect slow to fast
	246-255	No function (shutter open)
7	5	7
	0-255	Dimmer intensity: Intensity 0 to 100%
	8	
	0-255	Fine Dimmer intensity: Dimmer intensity fine
8	6	9
	0-255	Zoom : Zoom adjustment from small to big
	10	
	0-255	Zoom Fine: Zoom adjustment Fine
9	7	11
	0-255	Focus : Continuous adjustment from near to far
	12	
	0-255	Focus Fine: Continuous adjustment Fine
10	8	13
	0-50	Auto Focus : Auto Focus Off
	51-100	5m
	101-150	7.5m
	151-200	10m
	201-255	15m
11	9	14
	0-255	AutoFocus Fine: Continuous adjustment Fine
12	10	15
	0-3	Color Wheel: Open / white
	4-7	Color 1
	8-11	Color 2
	12-15	Color 3
	16-19	Color 4
	20-23	Color 5
	24-27	Color 6
	28-127	Color indexing
	128-189	Forwards rainbow effect from fast to slow
	190-193	No rotation
	194-255	Backwards rainbow effect from slow to fast
	16	
	0-255	Color Wheel Fine: Color Wheel colour change to any position Fine

13	11	17		Cyan Color :
		0-255		Cyan (0-white, 255-100% Cyan)
		18		Cyan Color Fine :
		0-255		Cyan Fine
14	12	19		Magenta Color :
		0-255		Magenta (0-white, 255-100% magenta)
		20		Magenta Color Fine :
		0-255		Magenta Fine
15	13	21		Yellow Color :
		0-255		Yellow (0-white, 255-100% Yellow)
		22		Yellow Color Fine :
		0-255		Yellow Fine
16	14	23		CTO Color :
		0-255		CTO (0-white, 255-100% CTO)
		24		CTO Color Fine :
		0-255		CTO Fine
17	15	25		CTB Color :
		0-255		CTB (0-white, 255-100% CTO)
		26		CTB Color Fine :
		0-255		CTB Fine
18	16	27		CTP Color :
		0-255		CTP (0-white, 255-100% CTO)
		28		CTP Color Fine :
		0-255		CTP Fine
19	17	29		Color Presets:
		0-255		See Appendix
20	18	30		Reserved
21	19	31		Reserved
22	20	32		Reserved
				Rotating gobos, cont. rotation 1:
		0-9		Open
		10-19		Rot. gobo 1
		20-29		Rot. gobo 2
		30-39		Rot. gobo 3
		40-49		Rot. gobo 4
		50-59		Rot. gobo 5
		60-69		Rot. gobo 6
		70-77		Rot. Gobo 7
23	21	33		78-93 Gobo 1 shake slow to fast
		94-109		Gobo 2 shake slow to fast
		110-125		Gobo 3 shake slow to fast
		126-141		Gobo 4 shake slow to fast
		142-157		Gobo 5 shake slow to fast
		158-173		Gobo 6 shake slow to fast
		174-189		Gobo 7 shake slow to fast
		190-221		Gobo wheel rotation forwards from fast to slow
		222-223		No rotation
		224-255		Gobo wheel rotation f backwards from slow to fast
				Rotating gobo index,rotating gobo rotation 1:
		0-127		Gobo indexing
24	22	34		128-189 Forwards gobo rotation from fast to slow
		190-193		No rotation
		194-255		Backwards gobo rotation from slow to fast
		35		Rotating gobo indexing Fine 1:
		0-255		Fine indexing

				Rotating gobos, cont. rotation 2:
			0-9	Open
			10-19	Rot. gobo 1
			20-29	Rot. gobo 2
			30-39	Rot. gobo 3
			40-49	Rot. gobo 4
			50-59	Rot. gobo 5
			60-69	Rot. gobo 6
			70-77	Rot. Gobo 7
25	23	36	78-93	Gobo 1 shake slow to fast
			94-109	Gobo 2 shake slow to fast
			110-125	Gobo 3 shake slow to fast
			126-141	Gobo 4 shake slow to fast
			142-157	Gobo 5 shake slow to fast
			158-173	Gobo 6 shake slow to fast
			174-189	Gobo 7 shake slow to fast
			190-221	Gobo wheel rotation forwards from fast to slow
			222-223	No rotation
			224-255	Gobo wheel rotation f backwards from slow to fast
				Rotating gobo index,rotating gobo rotation 2:
26	24	37	0-127	Gobo indexing
			128-189	Forwards gobo rotation from fast to slow
			190-193	No rotation
			194-255	Backwards gobo rotation from slow to fast
		38		Rotating gobo indexing Fine 2:
			0-255	Fine indexing
				Animation wheel 1:
27	25	39	0-7	No rotation
			8-127	Forwards rotation from fast to slow
			128-135	No rotation
			136-255	Backwards rotation from slow to fast
28	26	40		Animation wheel 2:
			0-255	Animation indexing
				Rotating Animation wheel 2:
29	27	41	0-7	No rotation
			8-127	Forwards rotation from fast to slow
			128-135	No rotation
			136-255	Backwards rotation from slow to fast
30	28	42		Iris:
			0-191	Max. diameter to Min.diameter
			192-223	Pulse closing fast to slow
			224-255	Pulse opening slow to fast
		43		Iris Fine:
			0-255	Iris Fine
				Prism 1:
31	29	44	0-127	Open
			128-255	Prism 1
				Rotating prism index, rotating prism rotation 1
32	30	45	0-127	Prism indexing
			128-189	Forwards prism rotation from fast to slow
			190-193	No rotation
			194-255	Backwards prism rotation from slow to fast
		46		Rotating prism indexing Fine 1:
			0-255	Fine indexing

33	31	47	0-127	Prism 2: Open
			128-255	Prism 2
34	32	48	0-127	Rotating prism index, rotating prism rotation 2 Prism indexing
			128-189	Forwards prism rotation from fast to slow
			190-193	No rotation
			194-255	Backwards prism rotation from slow to fast
		49		Rotating prism indexing Fine 2: Fine indexing
35	33	50		Frost 1: 0-255 0-100%
				Frost 2: 0-255 0-100%
36	34	51		Blade 1A : 0-255 Open to Close
				Blade 1A Fine : 0-255 Open to Close Fine
38	36	54		Blade 1B : 0-255 Open to Close
				Blade 1B Fine : 0-255 Open to Close Fine
39	37	56		Blade 2A : 0-255 Open to Close
				Blade 2A Fine : 0-255 Open to Close Fine
40	38	58		Blade 2B : 0-255 Open to Close
				Blade 2B Fine : 0-255 Open to Close Fine
41	39	60		Blade 3A : 0-255 Open to Close
				Blade 3A Fine : 0-255 Open to Close Fine
42	40	62		Blade 3B : 0-255 Open to Close
				Blade 3B Fine : 0-255 Open to Close Fine
43	41	64		Blade 4A : 0-255 Open to Close
				Blade 4A Fine : 0-255 Open to Close Fine
44	42	66		Blade 4B : 0-255 Open to Close
				Blade 4B Fine : 0-255 Open to Close Fine
45	43	68		All Blade Rotation : 0-255 All Blade Rotation
				All Blade Rotation Fine : 0-255 All Blade Rotation Fine
46	44	70		Control, reset, internal programs: 0-4 unused
				5-9 Display Off
				10-14 Display On
				15-19 Display Invert Off
				20-24 Display Invert On
				25-26 Auto fan control mode
				27-28 Stage fan control mode
				29-30 Silence fan control mode
				31-32 Super Silence fan control mode
				33-34 Constant Fans Off
				35-36 Constant Fans On
				37-44 unused
				45-49 Square Law
				50-54 Linear
				55-58 1.2K
				59-62 2.4K
				63-66 16K
				67-69 25K
				70-74 Gobo correction Off
				75-79 Gobo correction On
				80-84 All motor reset
				85-87 Scan motor reset
				88-90 Colors motor reset
				91-93 Gobo motor reset
				94 unused
				95 Reset P/T Fade Off
				96 Reset P/T Fade On
	97-99 Other motor reset			
	100-102 Frost Progressive Off			
	103-105 Frost Progressive On			
	106-108 CMY speed Fast			
	109-111 CMY speed Slow			
	112-255 unused			

Mode/Channel	Value	Function
Domino Mode		
1		PAN Movement 8bit :
	0-255	Pan Movement
2		Pan Fine 16bit
	0-255	Fine control of Pan movement
3		TILT Movement 8bit :
	0-255	Tilt Movement
4		Tilt Fine 16bit
	0-255	Fine control of Tilt movement
5		Speed Pan/Tilt movement:
	0-225	max to min speed
	226-235	blackout by movement
	236-245	blackout by all wheel changing
6	246-255	no function
		Shutter, strobe:
	0-10	Shutter closed
	11-20	No function (shutter open)
	21-117	Strobe effect slow to fast
	118-126	No function (shutter open)
	127-180	Pulse-effect in sequences
7	181-191	No function (shutter open)
	192-245	Random strobe effect slow to fast
	246-255	No function (shutter open)
		Dimmer intensity:
	0-255	Intensity 0 to 100%
8		Fine Dimmer intensity:
	0-255	Dimmer intensity fine
12		Zoom :
	0-255	Zoom adjustment from small to big
13		Zoom Fine:
	0-255	Zoom adjustment Fine
14		Focus :
	0-255	Continuous adjustment from near to far
15		Focus Fine:
	0-255	Continuous adjustment Fine
16		Auto Focus :
	0-50	Auto Focus Off
	51-100	5m
	101-150	7.5m
	151-200	10m
17	201-255	15m
		AutoFocus Fine:
18	0-255	Continuous adjustment Fine
		Color Wheel:
	0-3	Open / white
	4-7	Color 1
	8-11	Color 2
	12-15	Color 3
	16-19	Color 4
	20-23	Color 5
	24-27	Color 6
	28-127	Color indexing
	128-189	Forwards rainbow effect from fast to slow
190-193	No rotation	
194-255	Backwards rainbow effect from slow to fast	
19		Color Wheel Fine:
	0-255	Color Wheel colour change to any position Fine
20		CTB/CRI:
	0-63	Open
	64-127	CTB
	128-255	unused
21		Cyan Color :
	0-255	Cyan (0-white, 255-100% Cyan)
22		Cyan Color Fine :
	0-255	Cyan Fine
23		Magenta Color :
	0-255	Magenta (0-white, 255-100% magenta)
24		Magenta Color Fine :
	0-255	Magenta Fine
25		Yellow Color :
	0-255	Yellow (0-white, 255-100% Yellow)
26		Yellow Color Fine :
	0-255	Yellow Fine
27		CTO Color :
	0-255	CTO (0-white, 255-100% CTO)
28		CTO Color Fine :
	0-255	CTO Fine
9		Reserved
10		Reserved
11		Reserved

		Rotating gobos, cont. rotation 1:
	0-9	Open
	10-19	Rot. gobo 1
	20-29	Rot. gobo 2
	30-39	Rot. gobo 3
	40-49	Rot. gobo 4
	50-59	Rot. gobo 5
	60-69	Rot. gobo 6
	70-77	Rot. Gobo 7
29	78-93	Gobo 1 shake slow to fast
	94-109	Gobo 2 shake slow to fast
	110-125	Gobo 3 shake slow to fast
	126-141	Gobo 4 shake slow to fast
	142-157	Gobo 5 shake slow to fast
	158-173	Gobo 6 shake slow to fast
	174-189	Gobo 7 shake slow to fast
	190-221	Gobo wheel rotation forwards from fast to slow
	222-223	No rotation
	224-255	Gobo wheel rotation f backwards from slow to fast
		Rotating gobo index,rotating gobo rotation 1:
	0-127	Gobo indexing
30	128-189	Forwards gobo rotation from fast to slow
	190-193	No rotation
	194-255	Backwards gobo rotation from slow to fast
		Rotating gobo indexing Fine 1:
31	0-255	Fine indexing
		Rotating gobos, cont. rotation 2:
	0-9	Open
	10-19	Rot. gobo 1
	20-29	Rot. gobo 2
	30-39	Rot. gobo 3
	40-49	Rot. gobo 4
	50-59	Rot. gobo 5
	60-69	Rot. gobo 6
	70-77	Rot. Gobo 7
32	78-93	Gobo 1 shake slow to fast
	94-109	Gobo 2 shake slow to fast
	110-125	Gobo 3 shake slow to fast
	126-141	Gobo 4 shake slow to fast
	142-157	Gobo 5 shake slow to fast
	158-173	Gobo 6 shake slow to fast
	174-189	Gobo 7 shake slow to fast
	190-221	Gobo wheel rotation forwards from fast to slow
	222-223	No rotation
	224-255	Gobo wheel rotation f backwards from slow to fast
		Rotating gobo index,rotating gobo rotation 2:
	0-127	Gobo indexing
33	128-189	Forwards gobo rotation from fast to slow
	190-193	No rotation
	194-255	Backwards gobo rotation from slow to fast
		Rotating gobo indexing Fine 2:
34	0-255	Fine indexing
		Animation wheel 1:
35	0	open
	1-239	Animation indexing
	240-255	shake slow to fast
		Animation wheel 1:
36	0-7	No rotation
	8-127	Forwards rotation from fast to slow
	128-135	No rotation
	136-255	Backwards rotation from slow to fast
		Animation wheel 2:
37	0-7	open
	8-127	Forwards rotation from fast to slow
	128-135	No rotation
	136-255	Backwards rotation from slow to fast
		Iris:
38	0-191	Max. diameter to Min.diameter
	192-223	Pulse closing fast to slow
	224-255	Pulse opening slow to fast
		Iris Fine:
39	0-255	Iris Fine
		Prism 1:
40	0-127	Open
	128-255	5-Facet Prism
		Rotating prism index, rotating prism rotation 1
	0-127	Prism indexing
41	128-189	Forwards prism rotation from fast to slow
	190-193	No rotation
	194-255	Backwards prism rotation from slow to fast
		Rotating prism indexing Fine 1:
42	0-255	Fine indexing

43	0-127	Prism 2: Open
	128-255	Linear Prism
44		Rotating prism index, rotating prism rotation 2
	0-127	Prism indexing
	128-189	Forwards prism rotation from fast to slow
	190-193	No rotation
45	194-255	Backwards prism rotation from slow to fast
		Rotating prism indexing Fine 2:
46	0-255	Fine indexing
		Frost 1:
47	0-255	0-100%
		Frost 2:
48	0-255	0-100%
		Blade 1A :
49	0-255	Open to Close
		Blade 1A Fine :
50	0-255	Open to Close Fine
		Blade 1B :
51	0-255	Open to Close
		Blade 1B Fine :
52	0-255	Open to Close Fine
		Blade 2A :
53	0-255	Open to Close
		Blade 2A Fine :
54	0-255	Open to Close Fine
		Blade 2B :
55	0-255	Open to Close
		Blade 2B Fine :
56	0-255	Open to Close Fine
		Blade 3A :
57	0-255	Open to Close
		Blade 3A Fine :
58	0-255	Open to Close Fine
		Blade 3B :
59	0-255	Open to Close
		Blade 3B Fine :
60	0-255	Open to Close Fine
		Blade 4A :
61	0-255	Open to Close
		Blade 4A Fine :
62	0-255	Open to Close Fine
		Blade 4B :
63	0-255	Open to Close
		Blade 4B Fine :
64	0-255	Open to Close Fine
		All Blade Rotation :
65	0-255	All Blade Rotation
		All Blade Rotation Fine :
66	0-255	All Blade Rotation Fine
		Control, reset, internal programs:
66	0-4	unused
	5-9	Display Off
	10-14	Display On
	15-19	Display Invert Off
	20-24	Display Invert On
	25-26	Auto fan control mode
	27-28	Stage fan control mode
	29-30	Silence fan control mode
	31-32	Super Silence fan control mode
	33-34	Constant Fans Off
	35-36	Constant Fans On
	37-44	unused
	45-49	Square Law
	50-54	Linear
	55-57	1.2K
	58-60	2.4K
	61-63	16K
	64-69	25K
	70-74	Gobo correction Off
	75-79	Gobo correction On
	80-84	All motor reset
	85-87	Scan motor reset
	88-90	Colors motor reset
	91-93	Gobo motor reset
	94	unused
	95	Reset P/T Fade Off
	96	Reset P/T Fade On
	97-99	Other motor reset
	100-102	Frost Progressive Off
	103-105	Frost Progressive On
	106-108	CMY speed Fast
	109-111	CMY speed Slow
112-255	unused	

Appendix:

name (=DMX value)	color name
EC003	LAVENDER TINT
EC004	MEDIUM BASTARD AMBER
EC007	PALE YELLOW
EC008	DARK SALMON
EC009	PALE AMBER GOLD
EC010	MEDIUM YELLOW
EC013	STRAW TINT
EC015	DEEP STRAW
EC017	SURPRISE PEACH
EC020	MEDIUM AMBER
EC021	GOLD AMBER
EC022	DARK AMBER
EC024	SCARLET
EC025	SUNSET RED
EC026	BRIGHT RED
EC029	PALSA RED
EC035	LIGHT PINK
EC036	MEDIUM PINK
EC046	DARK MAGENTA
EC048	DARK PURPLE
EC052	LIGHT LAVENDER
EC053	PALE LAVENDER
EC058	LAVENDER
EC063	PALE BLUE
EC068	SKY BLUE
EC071	TOKIO BLUE
EC075	EVENING BLUE
EC079	JUST BLUE
EC085	DEEPER BLUE
EC088	LIME GREEN
EC089	MOSS GREEN
EC090	DARKYELLOW GREEN
EC100	SPRING YELLOW
EC101	YELLOW
EC102	LIGHT AMBER
EC103	STRAW
EC104	DEEP AMBER
EC105	ORANGE
EC106	PRIMAY RED
EC107	LIGHT ROSE
EC108	ENGLISH ROSE
EC109	LIGHT SALMON
EC110	MIDDLE ROSE
EC111	DARK PINK
EC113	MAGENTA

EC116	MEDIUM BLUE GREEN
EC118	LIGHT BLUE
EC119	DARK BLUE
EC120	DEEP BLUE
EC124	DARK GREEN
EC126	MAUVE
EC127	SMOKEY PINK
EC128	BRIGHT PINK
EC132	MEDIUM BLUE
EC134	GOLDEN AMBER
EC136	PALE LAVENDER
EC137	SPECIAL LAVENDER
EC138	PALE GREEN
EC139	PRIMARY GREEN
EC140	SUMMER BLUE
EC141	BRIGHT BLUE
EC142	PALE VIOLET
EC143	PALE NAVY BLUE
EC147	APRICOT
EC148	BRIGHT ROSE
EC151	GOLD TINT
EC152	PALE GOLD
EC153	PALE SALMON
EC154	PALE ROSE
EC156	CHOCOLATE
EC158	DEEP ORANGE
EC159	NO COLOR STRAW
EC161	SLATE BLUE
EC162	BASTARD AMBER
EC164	FLAME RED
EC165	DAYLIGHT BLUE
EC169	LILAC TINT
EC170	DEEP LAVENDER
EC172	LAGOON BLUE
EC174	DARK STEEL BLUE
EC176	LOVING AMBER
EC179	CHROME ORANGE
EC180	DARK LAVENDER
EC181	CONGO BLUE
EC182	LIGHT RED
EC183	MOONLIGHT BLUE
EC192	FLESH PINK
EC193	ROSY AMBER
EC194	SURPRISE PINK
EC195	ZENITH BLUE
EC196	TRUE BLUE
EC197	ALICE BLUE
EC198	PALACE BLUE